



# HFClock 8250-TEMP-01 Installation Instructions

1. **Power-OFF** Clock by Unplugging from AC!
2. Place Clock Face-Down on Soft Cloth
3. Remove Label to Access Connector



4. Take Sensor Out of Protective Bag
5. Gently Install Sensor Pins into Socket



6. Confirm that Sensor is Properly Seated
7. Plug Clock into AC Mains Receptacle
8. Clock Automatically Detects Sensor
9. Data Visible by Scrolling Solar Images